

- DO NOT ATTACH DUCT TO TOP OF LOWER LOUVER BLADE AS TYPICAL. THIS CREATES SEALING PROBLEMS AT MULLIONS AND OTHER VERTICAL MEMBERS.
- CONSTRUCT SLEEVE AND DUCTWORK TO SUPPORT WEIGHT OF SERVICE TECHNICIAN.
- 3. SEAL JOINT BETWEEN DUCT AND SLEEVE WATER TIGHT ALL AROUND.
- 4. INSULATE DUCT AND SLEEVE AS SPECIFIED.

## NOTE TO A/E:

- INDICATE WORK TO BE DONE BY GENERAL CONTRACTOR AND VENT CONTRACTOR.
- OUTSIDE AIR PLENUM IS PREFERRED. SEE OUTSIDE AIR PLENUM CONSTRUCTION DETAIL.

## WALL LOUVER DETAIL

SCALE: NO SCALE

Detail Title:	Detail No.:	23 37 00 - 01		
WALL LOUVER DETAIL	Scale:	N.T.S.	Facilities, Planning & Capital Programs Standard Detail	<b>Nebraska</b>
	Date:	October 2020		-

A1.01